




1. Right-click on the device and click on "Update driver"



2. Click on "Browse my computer for drivers"



3. Click on "Let me pick from a list of available drivers on my computer"



4. Select the "USB Test and Measurement Device (IVI)" driver and click on "Next"

