

PERMANENT MAGNET HOMOGENEITY MEASUREMENT SHEET

S/N 008

B nom [T] 0.2896108

| Point | B [T] | B [ppm] |
|-------|-----------|---------|
| 0 | 0.2896108 | 0.0 |
| -1 | 0.2896077 | -10.7 |
| 1 | 0.2896117 | 3.1 |
| 1 | 0.2896157 | 16.9 |
| -1 | 0.2896093 | -5.2 |
| -2 | 0.2896080 | -9.7 |
| 2 | 0.2896161 | 18.3 |
| 2 | 0.2896246 | 47.7 |
| -2 | 0.2896109 | 0.3 |
| -3 | 0.2896115 | 2.4 |
| 3 | 0.2896226 | 40.7 |
| 3 | 0.2896367 | 89.4 |
| -3 | 0.2896136 | 9.7 |
| -4 | 0.2896192 | 29.0 |
| 4 | 0.2896321 | 73.5 |
| 4 | 0.2896515 | 140.5 |
| -4 | 0.2896177 | 23.8 |
| -5 | 0.2896280 | 59.4 |
| 5 | 0.2896438 | 113.9 |
| 5 | 0.2896684 | 198.9 |
| -5 | 0.2896230 | 42.1 |

